



MAX TRAC SUSPENSION  
4522 E. EISENHOWER CIR.  
ANAHEIM, CA 92807  
714-630-0363  
[WWW.MAXTRACSUSPENSION.COM](http://WWW.MAXTRACSUSPENSION.COM)  
[SALES@MAXTRACSUSPENSION.COM](mailto:SALES@MAXTRACSUSPENSION.COM)

**PRODUCT: 836800**  
**DIFFERENTIAL DROP BRACKETS & SKID PLATE SPACER**

**PARTS LIST QTY**

DIFFERENTIAL SPACER	2
SKID PLATE SPACER	3
HEX BOLT 9/16" – 18 X 6"	2
FLAT WASHER 9/16"	2
NYLOCK NUT 9/16 – 18	2
HEX BOLT M8 – 1.25 x 30MM	3
FLAT WASHER 8MM	3

PLEASE DOUBLE CHECK THE PARTS LIST BEFORE BEGINNING INSTALLATION TO ENSURE ALL PARTS ARE PRESENT. IF THERE IS SOMETHING MISSING, PLEASE CONTACT MAX TRAC IMMEDIATELY 714-630-0363

READ THE INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE BEGINNING THE INSTALLATION.

**PRIOR TO INSTALLATION:**

1. Factory service manual is recommended to have on hand.
2. Secure and properly block vehicle prior to beginning installation.
3. Always wear safety glasses when using power tools or working under the vehicle.
4. Modifications to any part will void the warranty associated with that product.

After removing parts from vehicle, save hardware for reinstallation

**IT IS RECOMMENDED THAT YOU HAVE YOUR VEHICLE'S ALIGNMENT CHECKED WHENEVER INSTALLING NEW SUSPENSION PRODUCTS. IT IS ALSO RECOMMENDED THAT YOU ADJUST YOUR HEADLIGHTS WHENEVER YOUR VEHICLE'S RIDE HEIGHT IS ALTERED.**

1. Drop down skid plate to access diff.



2. Remove front differential mounts and loosen rear dif. mount for ease of install on the front differential spacers



3. DIFFERENTIAL DROP INSTALLED



#### 4WD VEHICLES ONLY, FOLLOW THESE INSTRUCTIONS FOR DIFFERENTIAL DROP

Remove front skid plate from the vehicle, then place a support or jack under the front differential. Remove the front differential mounting bolts, and lower enough to install new spacers. The 1" spacers install between the frame and the mounts. Install with the provided longer bolts and factory washers. Torque to factory spec, and reinstall the skid plate with the provided 1/2" tall spacers with longer bolts.

SEE PHOTOS BELOW

4. SKID PLAT SPACER INSTALLED

