

841413 SHOCK EXTENDER INSTALLATION



- 1) UNBOLT THE TWO STUDS AT THE TOP OF THE FRONT SHOCKS**
- 2) SLIDE THE PROVIDED SPACERS OVER THE STUDS**
- 3) RE-INSTALL THE SHOCK INTO THE TOWER AND TIGHTEN NUTS**