



MAXTRAC SUSPENSION
4522 E EISENHOWER CIR
ANAHEIM, CA 92807
714-630-0363
WWW.MAXTRACSUSPENSION.COM
SALES@MAXTRACSUSPENSION.COM

**PRODUCT: 541500 REAR LIFT SHOCK EXTENDERS
2014 GM 1500 PICKUP 2WD & 4WD**

PARTS LIST QTY

SHOCK EXTENDER	2
M14-2.0X80 HEX CAP SCREW	2
M14-2.0 NYLOCK NUT	2
M14 FLAT WASHER	4

PLEASE DOUBLE CHECK THE PARTS LIST BEFORE BEGINNING INSTALLATION, TO ENSURE ALL PARTS ARE PRESENT, IF THERE IS SOMETHING MISSING, PLEASE CONTACT MAXTRAC IMMEDIATELY 714-630-0363

READ THE INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE BEGINNING THE INSTALLATION.

PRIOR TO INSTALLATION:

1. Factory service manual is recommended to have on hand.
2. Secure and properly block vehicle prior to beginning installation
3. Always wear safety glasses when using power tools or working under the vehicle
4. Modifications to any part will void the warranty associated with that product.

After removing parts from vehicle, save hardware for reinstallation

IT IS RECOMMENDED THAT YOU HAVE YOUR VEHICLE'S ALIGNMENT CHECKED WHENEVER INSTALLING NEW SUSPENSION. IT IS ALSO RECOMMENDED THAT YOU ADJUST YOUR HEADLIGHTS WHENEVER YOUR VEHICLE'S RIDE HEIGHT IS ALTERED.

INSTALLATION INSTRUCTIONS - 541500

1. SUPPORT AXLE WITH AN ADJUSTABLE JACK & UNBOLT BOTH REAR SHOCKS FROM THE FRAME



2. INSTALL MAXTRAC EXTENDER INTO THE ORIGINAL SHOCK MOUNT USING FACTORY HARDWARE & TIGHTEN.



3. INSTALL THE SHOCK INTO THE MAXTRAC SHOCK EXTENDER USING THE PROVIDED HARDWARE & TIGHTEN.

