

401000/401003/401004

2000-2020 GM SUV/AVALANCHE REAR SHOCK EXTENDERS

- 1) SUPPORT THE REAR AXLE WITH AN ADJUSTABLE JACK AND UNBOLT BOTH REAR SHOCKS FROM THE AXLE
- 2) FIND WHICH EXTENDER FITS ON WHICH SIDE (THEY ARE SIDE SPECIFIC) AND SLIDE THE EXTENDER OVER THE FACTORY SHOCK MOUNT
- 3) INSERT THE PROVIDED BOLT FROM THE OUTSIDE, FACING INWARD THROUGH THE ORIGINAL SHOCK MOUNT HOLES AND ONE VERTICALLY THROUGH THE BOTTOM OF THE EXTENDER INTO THE FACTORY HOLE.
- 4) ONCE ALL 3 BOLTS ARE INSTALLED, TIGHTEN THEM. THEN RE-INSTALL THE SHOCK USING THE FACTORY HARDWARE AND TIGHTEN.

