



**PART# 530713**

**2001-2010 GM 2500/3500 2WD/4WD**

**FRONT LIFT SHOCK EXTENDERS**



**1 HOUR INSTALL TIME**

Components
(2) SHOCK EXTENDERS

**Please double check the parts list before beginning installation to ensure all parts are present. If there is something missing, please contact Maxtrac Suspension (714) 630-0363. Please have the boxes present if parts are missing or damaged**

**PRIOR TO INSTALLATION:**

- 1. Factory service manual is recommended to have on hand.**
- 2. Secure and properly block vehicle prior to beginning installation.**
- 3. Always wear safety glasses when using power tools or working under the vehicle**
- 4 Modification to any part will void the warranty associated with that product**

**AFTER REMOVING PARTS FROM VEHICLE, SAVE HARDWARE FOR REINSTALLATION**



**Step 1** Jack up the front of the truck and support under the frame rails with jack stands.



**Step 2** One side at a time, unbolt the shock from the mount on the control arm and then unbolt the mount from the control arm and remove.



**Step 3** Attach the new shock mount using the factory hardware. Make sure the straight edge is facing the engine. Next, attach the shock using the factory hardware and tighten. **NOTE: THIS EXTENDER IS INTENDED TO BE USED WITH A STOCK LENGTH SHOCK.**