

400900 REAR SHOCK ANGLE CORRECTER

1999-2006 GM 1500 2WD/4WD

- 1) AFTER THE FLIP KIT IS INSTALLED AND YOU ARE READY TO INSTALL THE SHOCKS, THIS ANGLE CORRECTOR WILL NEED TO BE INSTALLED ONTO THE PASSENGER SIDE SHOCK MOUNT ON THE AXLE.
- 2) SLIDE THE ANGLE CORRECTOR OVER THE ORIGINAL MOUNT, LOOSELY INSTALL THE TWO PROVIDED $\frac{1}{2}$ " BOLTS THROUGH THE ORIGINAL SHOCK BOLT HOLES AND DRILL A $\frac{3}{8}$ " HOLE THROUGH THE BACK SIDE OF THE MOUNT USING THE ANGLE CORRECTOR AS A GUIDE.



- 3) INSTALL THE PROVIDED $\frac{3}{8}$ " BOLT THROUGH THE DRILLED HOLE AND TIGHTEN ALL BOLTS. THEN INSTALL THE SHOCK IN TO THE ANGLE CORRECTOR USING THE ORIGINAL HARDWARE. (PIC 400900 INSTALLED)



4)