

READ THE INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE BEGINNING THE INSTALLATION.



**PART# 990962**  
**AUTO RIDE REAR SENSOR RODS**  
**2000-UP GM SUV'S**

PARTS LIST

2	SENSOR RODS
---	-------------



Approximate install time 10 min.



**REAR SENSOR RODS**  
THREADED FOR ADJUSTABILITY

**NOTE**

Please double check the parts list before beginning installation, to ensure all parts are present. if there is something missing, please contact Maxtrac Suspension immediately (714) 630-0363.

**PRIOR TO INSTALLATION:**

1. **Factory service manual is recommended to have on hand.**
2. **Secure and properly block vehicle prior to beginning installation**
3. **Always wear safety glasses when using power tools or working under the vehicle**
4. **Modifications to any part will void the warranty associated with that product.**

**AFTER REMOVING PARTS FROM VEHICLE, SAVE HARDWARE FOR REINSTALLATION.**

**STEP 1:** Remove the factory sensor rods by popping them off of the factory ball connectors.

**STEP 2:** For model years 2000-2013 the factory rod ends are pressed on or glued on so they will be tough to remove. you will need to pull or pry and they will pop off the rod.

For model years 2015 to current the rod ends are held on by a retaining lip and groove. They can easily be removed by clamping the rod in a vise and prying off with a set of pliers.

**STEP 3:** Screw the factory rod ends onto the MaxTrac shorter sensor rods until they bottom out and then re-install.



**NOTE:** When installing 3" or 4" drop coils, the rods will need be trimmed.  
3", Trim 1/8" off of each end of the rod. (The rod should measure 2 1/2" EYE-EYE w/ rod ends on)  
4", Trim 1/4" off of each end of the rod. (The rod should measure 2 1/4" EYE-EYE w/ rod ends on)

**NOTE**

**IT IS RECOMMENDED THAT YOU HAVE YOUR VEHICLE'S ALIGNMENT CHECKED WHENEVER INSTALLING NEW SUSPENSION. IT IS ALSO RECOMMENDED THAT YOU ADJUST YOUR HEADLIGHTS WHENEVER YOUR VEHICLE'S RIDE HEIGHT IS ALTERED.**