

400500

REAR SHOCK ANGLE CORRECTORS

1988-1998 GM 1500 2WD/4WD

- 1) AFTER THE FLIP KIT IS INSTALLED AND YOU ARE READY TO INSTALL THE SHOCKS, THESE SHOCK ANGLE CORRECTORS NEED TO BE INSTALLED ON THE AXLE'S SHOCK MOUNT FIRST.
- 2) SLIDE THE ANGLE CORRECTOR OVER THE ORIGINAL MOUNT, LOOSELY INSTALL THE TWO PROVIDED $\frac{1}{2}$ " BOLTS THROUGH THE ORIGINAL SHOCK BOLT HOLES AND DRILL A $\frac{3}{8}$ " HOLE THROUGH THE BACK SIDE OF THE MOUNT USING THE ANGLE CORRECTOR AS A GUIDE.
- 3) INSTALL THE PROVIDED $\frac{3}{8}$ " BOLT THROUGH THE DRILLED HOLE AND TIGHTEN ALL BOLTS. THEN INSTALL THE SHOCK IN TO THE ANGLE CORRECTOR USING THE ORIGINAL HARDWARE.

