




PART# 836925

**1995.5-2004 TOYOTA TACOMA (6 LUG)
1995.5-2002 TOYOTA 4RUNNER (6 LUG)**



2.5" FRONT STRUT SPACERS



3 HOUR INSTALL TIME



RECOMMENDED 32" X 11.5" TIRE ON A 17" X 9" RIM WITH 4.5" BACK SPACING

Components	Hardware
(2) 836925 STRUT SPACER	(6) M10-1.25 FLANGE NUT

Please double check the parts list before beginning installation to ensure all parts are present. If there is something missing, please contact Maxtrac Suspension (714) 630-0363. Please have the boxes present if parts are missing or damaged

PRIOR TO INSTALLATION:

- 1. Factory service manual is recommended to have on hand.**
- 2. Secure and properly block vehicle prior to beginning installation.**
- 3. Always wear safety glasses when using power tools or working under the vehicle**
- 4 Modification to any part will void the warranty associated with that product**

AFTER REMOVING PARTS FROM VEHICLE, SAVE HARDWARE FOR REINSTALLATION



Step 1 Jack up the front of the of the vehicle and support under the frame rails with jack stands. Remove both front tires and proceed with one side at a time.



Step 2 Unbolt the sway bar end link from the sway bar and remove the upper bushing/washer.




Step 3 Remove all 3 of the strut top mounting nuts and the sindle, lower strut mounting bolt.



Step 4 Unbolt the 4 bolts attaching the lower ball joint to the steering knuckle and allow it to separate.



Step 5 Remove the strut and attach the strut spacer to the top using the factory nuts, then tighten.



Step 6 Install the strut assembly back into the truck using the provided flange nuts at the top and the stock bolt at the bottom. **NOTE: DO NOT FULLY TIGHTEN THE LOWER BOLT UNTIL THE TRUCK IS BACK ON THE GROUND AT RIDE HEIGHT.**



STEP
7

Step 7 Use a floor jack under the lower control arm to compress the coil and then re-install the factory lower ball joint nuts and tighten to factory specs.



STEP
8



STEP
8

Step 8 Repeat steps 1-7 on the other side. Once both sides have been installed, re-install the sway bar bushings/washers and tighten them down using the factory nut.

- Make sure to check the vehicle's tow before driving.
- The headlights should be adjusted after modifying the stance of the vehicle.
- The vehicle's alignment will need to be adjusted.
- All suspension components should be re-torqued after 500 miles.